



## NTSC CHANNEL LIST

#	ACCESS#	CHANNEL	FREQ. MHz
1	160	CH.160	7.00
2	161	CH.161	13.00
3	162	CH.162	19.00
4	163	CH.163	25.00
5	164	CH.164	31.00
6	165	CH.165	37.00
7	166	CH.166	43.00
8	167	CH.167	49.00
9	2	CH.2	55.25
10	3	CH.3	61.25
11	4	CH.4	67.25
12	1	CH.1	73.25
13	5	CH.5	79.25
14	6	CH.6	85.25
15	95	CH.95	91.25
16	96	CH.96	97.25
17	97	CH.97	103.25
18	98	CH.98	109.25
19	99	CH.99	115.25
20	14	CH.14	121.25
21	15	CH.15	127.25
22	16	CH.16	133.25
23	17	CH.17	139.25
24	18	CH.18	145.25
25	19	CH.19	151.25
26	20	CH.20	157.25
27	21	CH.21	163.25
28	22	CH.22	169.25
29	7	CH.7	175.25
30	8	CH.8	181.25
31	9	CH.9	187.25
32	10	CH.10	193.25
33	11	CH.11	199.25
34	12	CH.12	205.25
35	13	CH.13	211.25
36	23	CH.23	217.25
37	24	CH.24	223.25
38	25	CH.25	229.25
39	26	CH.26	235.25
40	27	CH.27	241.25
41	28	CH.28	247.25
42	29	CH.29	253.25
43	30	CH.30	259.25
44	31	CH.31	265.25
45	32	CH.32	271.25
46	33	CH.33	277.25
47	34	CH.34	283.25
48	35	CH.35	289.25

#	ACCESS#	CHANNEL	FREQ. MHz
49	36	CH.36	295.25
50	37	CH.37	301.25
51	38	CH.38	307.25
52	39	CH.39	313.25
53	40	CH.40	319.25
54	41	CH.41	325.25
55	42	CH.42	331.25
56	43	CH.43	337.25
57	44	CH.44	343.25
58	45	CH.45	349.25
59	46	CH.46	355.25
60	47	CH.47	361.25
61	48	CH.48	367.25
62	49	CH.49	373.25
63	50	CH.50	379.25
64	51	CH.51	385.25
65	52	CH.52	391.25
66	53	CH.53	397.25
67	54	CH.54	403.25
68	55	CH.55	409.25
69	56	CH.56	415.25
70	57	CH.57	421.25
71	58	CH.58	427.25
72	59	CH.59	433.25
73	60	CH.60	439.25
74	61	CH.61	445.25
75	62	CH.62	451.25
76	63	CH.63	457.25
77	64	CH.64	463.25
78	65	CH.65	469.25
79	66	CH.66	475.25
80	67	CH.67	481.25
81	68	CH.68	487.25
82	69	CH.69	493.25
83	70	CH.70	499.25
84	71	CH.71	505.25
85	72	CH.72	511.25
86	73	CH.73	517.25
87	74	CH.74	523.25
88	75	CH.75	529.25
89	76	CH.76	535.25
90	77	CH.77	541.25
91	78	CH.78	547.25
92	79	CH.79	553.25
93	80	CH.80	559.25
94	81	CH.81	565.25
95	82	CH.82	571.25
96	83	CH.83	577.25

#	ACCESS#	CHANNEL	FREQ. MHz
97	84	CH.84	583.25
98	85	CH.85	589.25
99	86	CH.86	595.25
100	87	CH.87	601.25
101	88	CH.88	607.25
102	89	CH.89	613.25
103	90	CH.90	619.25
104	91	CH.91	625.25
105	92	CH.92	631.25
106	93	CH.93	637.25
107	94	CH.94	643.25
108	100	CH.100	649.25
109	101	CH.101	655.25
110	102	CH.102	661.25
111	103	CH.103	667.25
112	104	CH.104	673.25
113	105	CH.105	679.25
114	106	CH.106	685.25
115	107	CH.107	691.25
116	108	CH.108	697.25
117	109	CH.109	703.25
118	110	CH.110	709.25
119	111	CH.111	715.25
120	112	CH.112	721.25
121	113	CH.113	727.25
122	114	CH.114	733.25
123	115	CH.115	739.25
124	116	CH.116	745.25
125	117	CH.117	751.25
126	118	CH.118	757.25
127	119	CH.119	763.25
128	120	CH.120	769.25
129	121	CH.121	775.25
130	122	CH.122	781.25
131	123	CH.123	787.25
132	124	CH.124	793.25
133	125	CH.125	799.25
134	126	CH.126	805.25
135	127	CH.127	811.25
136	128	CH.128	817.25
137	129	CH.129	823.25
138	130	CH.130	829.25
139	131	CH.131	835.25
140	132	CH.132	841.25
141	133	CH.133	847.25
142	134	CH.134	853.25
143	135	CH.135	859.25
144	136	CH.136	865.25

#	ACCESS#	CHANNEL	FREQ. MHz
145	137	CH.137	871.25
146	138	CH.138	877.25
147	139	CH.139	883.25
148	140	CH.140	889.25
149	141	CH.141	895.25
150	142	CH.142	901.25
151	143	CH.143	907.25
152	144	CH.144	913.25
153	145	CH.145	919.25
154	146	CH.146	925.25
155	147	CH.147	931.25
156	148	CH.148	937.25
157	149	CH.149	943.25
158	150	CH.150	949.25
159	151	CH.151	955.25
160	152	CH.152	961.25
161	153	CH.153	967.25
162	154	CH.154	973.25
163	155	CH.155	979.25
164	156	CH.156	985.25
165	157	CH.157	991.25
166	158	CH.158	997.25
167	159	CH.159	1003.25
168			
169			
170			
171			
172			
173			
174			
175			
176			
177			
178			
179			
180			
181			
182			
183			
184			
185			
186			
187			
188			
189			
190			
191			
192			